




Standard specifications

MC500P-01 [FD11]

4th edition



NACHI-FUJIKOSHI CORP.

2402, SMCEN-092-004,001



Table of contents

1. Outline.....	1
2. Basic specifications.....	2
3. Robot dimensions and motion range.....	4
4. Detail of load installation plate.....	5
5. Installation procedure.....	7
6. Allowable wrist load.....	11
7. Option specifications.....	15
8. Application wiring and piping diagram.....	16
9. Transport procedure.....	21
10. Terms of Delivery and Installation (Specification that contains robot)	22
11. Consuming power (Robot + Controller)	22
12. Paint color	22
13. Warranty.....	22

1. Outline

“NACHI ROBOT” has used mechatronic techniques, cultivated throughout the last few decades, to supply robots suited for industries utilizing welding and the material handling techniques.

“MC500P” is a robot of simple highly rigid structure which is optimal for material handling application.

Maximum payload	500kg
Mounting condition	
Floor	MC500P-01

■ Characteristics

1. Due to high wrist torque and high moment of inertia, this robot is suitable for handling of heavy payload.
2. Wide motion range makes easier applicability than before.
3. By installing the balance unit inside arm, swivel base becomes slim and interference radius gets substantially shorter than before.
4. Due to making higher maximum speed, cycle time is shortened. Also it is possible to get faster air-cut motion that is changing wrist attitude widely.
5. By hollow forearm and wrist, cables to end effector are installed inside arm. So it is possible to install robot in narrow space where used to be difficult to install it.

2. Basic specifications

Item		Specifications
Robot type		MC500P-01
Structure		Articulated
Degree of Freedom		5
Drive system		AC servo motor
Maximum motion range	Axis 1	± 3.14 rad ($\pm 180^\circ$)
	Axis 2	$-1.83 \sim +1.05$ rad ($-105 \sim +60^\circ$)
	Axis 3	$-2.27 \sim +0.52$ rad ($-130 \sim +30^\circ$)
	Axis 5	± 2.09 rad ($\pm 120^\circ$) *6
	Axis 6	MAX: ± 6.28 rad ($\pm 360^\circ$) INITIAL SETTING: ± 3.67 rad ($\pm 210^\circ$) *4
Maximum Velocity	Axis 1	1.57 rad/s ($90^\circ/\text{s}$)
	Axis 2	1.57 rad/s ($90^\circ/\text{s}$)
	Axis 3	1.57 rad/s ($90^\circ/\text{s}$)
	Axis 5	1.92 rad/s ($110^\circ/\text{s}$)
	Axis 6	3.14 rad/s ($180^\circ/\text{s}$)
Maximum pay load	Wrist	500 kg
	Forearm *1	25 kg at maximum
Maximum static load torque	Axis 5	3450 N·m
	Axis 6	1725 N·m
Maximum moment of inertia *2	Axis 5	600 kg·m ²
	Axis 6	400 kg·m ²
Position repeatability *3		± 0.09 mm
Mounting Condition		Floor
Ambient conditions		Temperature: 0 to 45 °C *5 Humidity: 20 to 85%RH (No dew, nor frost allowed) Vibration to the installation face: Not more than 0.5G (4.9 m/s ²)
Robot weight		3,350 kg

1[rad] = $180/\pi$ [°], 1[N·m] = 1/9.8[kgf·m]

- Axis 1 - Axis 6 are displayed as J1-J6 each on the controller screen.
- Specifications are subject to change without prior notice for technical changes.
- The explosion-proof version is not available.

*1: This value changes by placement and load conditions of a wrist. *2: Maximum moment of inertia of a wrist changes depending on the load conditions of a wrist. *3: JIS B 8432 conformance. *4: The initial setting of the software limit is $\pm 210^\circ$. When installing the cables in the hollow hole part of axis 6, please use the robot in the range of $\pm 210^\circ$. If the cables do not go through the hollow hole of axis 6, it is possible to widen the motion range of axis 6 up to $\pm 360^\circ$ considering the condition. For details of how to change the software limit range, refer to the instruction manual **"SETUP MANUAL"** (Chapter 4). *5: Using at 1000m or lower sea level. Ambient temperature has limitations when allowable altitude is exceeded. *6: Axis 5 is controlled in the range of vertically downward $\pm 5^\circ$ by the software. Only at the state of opening the encoder correction screen or operation range setting screen, axis 5 becomes possible to operate $\pm 120^\circ$.




Position repeatability is defined in accordance with JIS B 8432 (ISO 9283) (Pose repeatability). Repeatability under the following conditions is not guaranteed.

- During repeated operation, the case in which approaching movement involves different directions and different orientations toward the measuring point.
- During repeated operation, the case in which payload condition changes. (for example, existence / no-existence of work-piece)
- During repeated operation, the case in which environment temperature changes. (Robot arm may cause the position repeatability to deteriorate.)
- The case in which position repeatability before and after warm-up is required.
- The case in which position repeatability of numeric position written in robot coordinate system and position in real space is required. (this is "Absolute position accuracy")
- The case in which position repeatability of position generated by shift command or palletize command and position in real space is required.

3. Robot dimensions and motion range

[MC500P-01]



- Axis 5 is controlled in the range of vertically downward $\pm 5^\circ$ by the software.
- Only at the state of opening the encoder correction screen or operation range setting screen, it becomes possible for axis 5 to operate $\pm 120^\circ$.

4. Detail of load installation plate

■ Wrist

For the end effector fixing bolts, use the installation P.C.D. shown in the following figures.




Be sure to screw the M12 tool fixing bolts in the wrist not deeper than the screw depth in the installation surface. Screwing the bolts deeper than the screw depth may damage the wrist.

[MC500P-01]


Tightening torque of
M12 Hex. socket head cap screw

JIS: Strength class 10.9	96 N·m
JIS: Strength class 12.9	116 N·m




■ Upper part of forearm

[MC500P-01]



■ Load mounting face of Extension flange

This flange is used for cables side routing (P.C.D.200).



Load mounting face of Extension flange OP-W3-015

5. Installation procedure

The installation location and the installation procedure of the robot are critical factors to maintain robot functions. The ambient conditions of installation location not only have influence on the life of mechanical sections of the robot, but also get involved in safety issues. Consequently, strictly observe the environmental conditions shown below. Furthermore, utmost care should be exerted for the installation procedure and the foundation for the robot in order to maintain the robot performance. Strictly observe the installation procedure for the robot provided below.

■ Safety measures against entry in the robot operating area

 WARNING	While the robot is in operation, workers are in danger of coming in contact with the robot. To avoid that, install a guard fence so as to keep the worker away from the robot. Not doing so will cause the workers or other persons to accidentally enter the operating area, thus resulting in accidents.
---	--

■ Safety measures for the robot and peripheral equipment locations

 WARNING	Do not install the operation and the adjustment part within the robot operating area. Install the robot control panel, interlock panel, and all the other operation panels where it's safe, so that they can be operated outside of the guard fence. In case those operation panels are installed near the robot, workers can get caught in the robot, when the robot operation fails.
---	--

■ Safety measures for installation work

 WARNING	To install the robot, it is important to install the robot so that no workers will get pinched or hurt by the robot or a device around them. The robot must not operate in the maximum operating range with a tool equipped on, and make sure not to touch any peripheral equipment.
 WARNING	Be sure to install the robot according to the specified procedure. Otherwise possibilities occur that robot's base may move or robot may fall over while in operation.
 WARNING	You must fully understand the connection procedure to make proper wire connections between the robot and the controller or the robot and the peripheral equipment. Not following the proper procedure will cause the malfunction of the robot.
 WARNING	Be sure to establish a proper grounding for the robot. If the equipment makes substantial noises such as a welder, conduct the specified grounding construction for the equipment.
 WARNING	Please pay extra attention not to damage wirings during transportation or installation of the robot. Furthermore, after installing the robot, apply protective guards to wirings so that it won't be damaged by workers or other persons, or forklift trucks or any other.
 WARNING	Installation structures (robot raiser, etc.) may cause problems such as vibration and servo tracking error. If such problem occurs, please promptly improve the installation structure. If installation structures are kept using as they are, reliability and lifetime of not only the robot but also the installation structures may be damaged, due to the vibration and sudden braking of robot.

■ Installation location and ambient conditions

Conditions (temperature, humidity, height and vibration) are written in “2. Basic Specifications”. Further ambient conditions listed below must be observed.

- (1) Location with the drainage structure so that swivel base is not flooded, when the liquid such as water or cutting fluid is splashed on the robot body
- (2) Location with no flammable or corrosive fluid or gas.
- (3) Type D grounding (the grounding resistance is 100Ω or less) is necessary.

 IMPORTANT	Our company's robot, controller and related option equipment are designed for general industrial use. Unless otherwise specified in the specifications or manuals, operations in special conditions and environments such as outdoor, X-ray environment, radiation environment, nuclear power control, aerospace equipment, public transportation, medical equipment, etc. are not assumed. Our company and its subsidiaries are not liable for any accidents, failures, etc., that may occur if the robot is used in such an environment without asking our company to do so.
 IMPORTANT	Using mounting condition that does not comply with specifications may cause the robot system to malfunction or fail prematurely. In that case, robot will be out of warranty. Please understand it in advance.

■ Installation procedure

While robot moves, large reaction force is applied to the swiveling base from all directions. Consequently, the robot should be installed in such a manner that the foundation endures reaction force caused by accelerating or decelerating the speed to lock the robot, not to mention that it endures static loads.

Repair uneven spots, cracks, and others on the floor, and then install the robot by following to the table below. If thickness of floor concrete is less than needed level, an independent foundation should be constructed. Inspect the foundation prior to the robot installation, and then construct the foundation, if necessary.

Robot Model	MC500P-01
Thickness of floor concrete	More than 160mm
Installation parts *1	8 bolts of M20 (JIS: Strength class 12.9) more than 70mm 8 plain washers of more than 4.5 mm in thickness and HRC35 in hardness
Tightening torque *2	560±30 N·m
Allowable repeated tensile *3	Approximately 56,000 N

*1 : Installation parts are not accessory of robot.

*2 : Apply a coating of lubricating oil to the threaded parts of bolts, and then tighten bolts by using torque wrench to the specified tightening torque.


*3 : This tensile is per installation bolt when robot is installed with all bolts written in table above.

■ Installation space


To install the robot, lock the swiveling base of the robot.

 WARNING	The mechanical stopper end is located in a position exceeding the specified motion range (software limit) of axis 1 by 3°. To install the safety fence, with consideration given to the wrist configuration and the shape of end effector.
 WARNING	On axes 1, 2 and 3, the robot motion range can be regulated for safety (optional function). Since optional parts should be installed to enable this function, do not independently move the standard parts (e.g. mechanical stopper).
 WARNING	If mechanical stopper collides and robot stops, it's possible that some parts are already damaged, for example, mechanical stopper is transformed or fixing bolts are broken. In this case, sufficient intensity and function can not be kept. Mechanical stopper and reduction gear of collided joint are needed to be replaced to the new one.

[MC500P-01]




[MC500P-01]




■ Accuracy of installation surface

When installing robot, strictly observe precautions listed below to cause no deformation in the swivel base.

- (1) Level of the flatness of 4 plates on the installation surface must be within 1.0 mm.
- (2) Keep the gap between the installation surface of 4 each base plates and the installation surface within 1.0 mm (± 0.5 mm) range in height.
- (3) Surface roughness of the base plate must be less than 25S with Rmax.



(3) In case, if it's difficult to follow the precautions described above, please use jack bolts to make 4 plates even towards the installation surface.





■ Welding of base plate

Protect the space (4 places of the front, back, left and right) on robot bottom and installed side by the cover etc. as follows when you weld with the base plate installed in the robot body by the welding spatter and the spark, etc. so that wiring in the robot should not receive damage. After welding the outer line, once remove the robot and weld the inner line.


Temporary install the robot, and weld the outer line of base plate.

Once remove the robot and weld the inner line.



■ Maximum robot generative force

Robot model	Max. vertical generative force F_v	Max. horizontal generative force F_H	Max. vertical generative moment M_v	Max. horizontal generative moment M_H
MC500P-01	95,300 N	69,500 N	260,400 N·m	225,800 N·m




6. Allowable wrist load

 CAUTION	The wrist load is regulated by the allowable payload mass, allowable static load torque, and allowable moment of inertia. If the wrist load exceeds beyond these allowable values, WE CANNOT GUARANTEE THE FUNCTION OF THE ROBOT. Please refer to “2. Basic specifications” and following figures for details of each specification.
 CAUTION	Before using the robot, please register the "weight", "COG (center of gravity) position" and "inertia Moment" of wrist payload as the load condition. Robot is controlled to minimize the operating time according to the registered value. Therefore, even if the load condition was within the specifications, if that is incorrect, excessive acceleration will be generated, and reliability and life may be damaged. Even if the correct value is registered, vibration or servo tracking error may occur due to the insufficient rigidity of the payload. If such problem occurs, please adjust the “speed”, “acceleration” and “smoothness”. Those factors can be adjusted in every step. See the instruction manual for details. FD controller instruction manual BASIC OPERATIONS (TCFEN-002) 4.3 Teaching

■ Torque map for the wrist load

Use the robot within the condition that COG of the wrist load stays in the range shown in the torque map.

[MC500P-01]




■ Map of Moment of inertia for the wrist load

Use the robot under condition that static load torque and moment of inertia stays in the range shown in the chart below.




If the load exceeds more than the Max. allowable moment then, maximum speed is automatically limited by the software to protect the robot.



[MC500P-01]



According to the degree of the inertia moment, the wrist operates with the appropriate speed.

■ Calculation of the wrist inertia moment




1 Calculate inertia moment on tool COG coordinate system (xyz). If tool is regarded as prism, it is calculated as right formula.	Inertia moment example on tool COG coordinate system If tool is regarded as prism  $I_x = \frac{1}{12} m \cdot (A^2 + B^2)$ $I_y = \frac{1}{12} m \cdot (A^2 + C^2)$ $I_z = \frac{1}{12} m \cdot (B^2 + C^2)$
2 Calculate inertia moment on wrist coordinate system (XYZ). If tool is regarded as aggregate of more than one solid, all inertia moment must be combined.	$I_X = m \cdot (Y_m^2 + Z_m^2) + I_x$ $I_Y = m \cdot (X_m^2 + Z_m^2) + I_y$ $I_Z = m \cdot (X_m^2 + Y_m^2) + I_z$ "Inertia moment on wrist coordinate system" is registered to controller.  Inertia moment on wrist coordinate system
3 Calculate inertia moment around robot wrist joint (axis 4, 5 and 6). This result must not be larger than "Allowable moment of inertia" written in robot specification sheet.	Axis 4 and 5 inertia moment is adopted larger value of around wrist coordinate system X and Y. (Because this depends on the axis 6 position.) Axis 6 inertia moment is around wrist coordinate system Z itself. $I_{J4} = I_{J5} = \max(I_X, I_Y)$ $I_{J6} = I_Z$

■ Load on the forearm

Use the robot within the condition that COG of the ancillary equipment on the forearm (: Arm of axis 3) stays in the range shown below.

[MC500P-01]



7. Option specifications

○: Compatible / —: Incompatible

No	Item	Specifications	Parts No.	Robot model
				MC500P-01
1	Installation parts *1	Chemical anchor specification Base plate welded (anchors not included)	OP-F1-037	○
		Hammar drive anchor specification Base plate welded (anchors not included)	OP-F2-022	○
		Installation bolts & washers	OP-F1-036	○
2	Extension flange	Side routing flange for cables (P.C.D.200)	OP-W3-015	○
3	Axis 1 adjustable stopper *1 (Including the dog for adjustable LS)	Restriction of axis 1 operation edge (±2.61 rad to every ±0, 0.13 rad)	OP-S5-027	○
4	Axis 2 adjustable stopper	Restriction of axis 2 operation edge (by changing the position of the standard parts) (-0.26 rad, -0.52 rad from the upper limit, -0.26 rad, -0.52 rad from the lower limit)	Standard	○
5	Axis 3 adjustable stopper *1	Restriction of axis 3 operation edge (-0.26 rad, -0.52 rad from the upper limit, -0.26 rad, -0.52 rad from the lower limit)	OP-A6-030	○
6	Axis 2 adjustable LS dog	Axis 2 axis adjustable limit switch dog set	OP-S8-009	○
7	Axis 3 adjustable LS dog	Axis 3 axis adjustable limit switch dog set	OP-S4-015	○
8	Transfer jig *3	Fork bracket (Front and back 2 directions)	OP-S2-046	○
9	Transfer jig *3	Fork bracket (Front, back, right and left 4 directions)	OP-S6-015	○
10	Zeroing pin & Zeroing block *1		OP-T2-097	○
11	Dual circuit limit switch	For axes 1, 2 and 3 (3pcs. of dual circuit LS)	Standard	○
12	Encoder connector Protector	For axis 2 and 3	OP-P6-010	○
13	Scale seal	For 5,6 axis	OP-N2-020	○
14	Gas balancer unit pressure gauge *1	Analog pressure gauge	KP-ZJ-013	○
		Digital pressure gauge	KP-ZJ-014	○
15	Gas balancer unit charging equipment *1 *2	Charging unit (W22, pitch14, Female)	KP-ZJ-015	○
		Charging unit (W23, pitch14, Male)	KP-ZJ-016	○
		Joint of Female->Male (W22)	KP-ZJ-019	○
16	Gas balancer support axis grease lubrication tool *1	Long nozzle for the Axis 2 support axis lubrication	KP-ZJ-069	○


*1 : These parts are packed separately from the robot. (Not attached on the robot)

*2 : If diameter of charging equipment (gas cylinder) is "W22, pitch14, Female, Right screw, Metal contacts", please prepare the charging equipment "KP-ZJ-015" and the joint "KP-ZJ-019".


*3 : Fork bracket (Front and back 2 directions) and Fork bracket (Front, back, right and left 4 directions) can not be used at the same time. Please select one of the two.

8. Application wiring and piping diagram

■ Standard specification [MC500P-01]




■ Upper part of forearm - Wiring and piping for application [MC500P-01]



(NOTE) In wiring box BJ3, there are application connectors shown in the next page
When connecting cables inside BJ3, select the adequate hole that corresponds to the cable size.


■ Base frame block - Wiring and piping for application [MC500P-01]



(NOTE) In wiring BOX (BJ1 BOX), there are connectors shown in the next pages.
And, to use the DeviceNet / Ethernet connectors, it is necessary to process the application cover.

■ Details of application connectors (standard) [MC500P-01]

(1) BJ1 side (connector)



User-side Connectors

Wire-side shell: JFM-WSA-4-A (JST)

or JFM-WSA-4-C (JST)

Guide plate A kit: JFM-GPAK-4 (JST)

Receptacle housing: JFM2FDN-22V-K (JST)

Receptacle contact:

a: SJ2F-01GF-P1.0 (JST) (0.20 ~ 0.50 mm²)

b: SJ2F-21GF-P1.0 (JST) (0.30 ~ 0.75 mm²)

Manual crimp tool:

a: YRS-8861

b: YRF-1120

Cable diameter suitable for wire-side shell:

JFM-WSA-4-A $\phi 26.2 \sim \phi 28.0$

JFM-WSA-4-C $\phi 15.5 \sim \phi 16.5$


(Shown pin assignment is a view from an insertion face of robot side connector.)

Application wiring specification

Rated voltage Max. AC/DC 115 V

Rated current rating Max. 1 A

(2) BJ3 side (connector)



Connector form (CN61, CN63)

Housing SMP-10V-BC (JST)

User-side Connectors

Housing SMR-10V-B (JST)

Contact SYM-001T-P0.6

(Applicable wire : AWG#22~28)

Manual crimp tool: YRS-121

Connector form (CN62, CN64)

Housing SMP-11V-BC (JST)

User-side Connectors

Housing SMR-11V-B (JST)


Contact SYM-001T-P0.6

(Applicable wire : AWG#22~28)

Manual crimp tool: YRS-121

■ Details of connectors for additional axis (Standard) [MC500P-01]

BJ3 side (Joint connector)



3	W7	2	V7	1	U7
6	G	5	BA7	4	PB7

Connector type (CNMB7B)

Housing VLP-06V (JST)

User-side connector



Housing VLR-06V (JST)

Retainer VLS-03V (JST)

Contact SVM-61T-P2.0

(Applicable wire: AWG#20~14)

Manual crimp tool: YC-590



Connector type (CNE7B)

Housing SMP-11V-BC (JST)

User-side connector

Housing SMR-11V-B (JST)

Contact SYM-001T-P0.6

(Applicable wire: AWG#22~28)

Manual crimp tool: YRS-121

1	2	3	4	5	6	7	8	9	10	11
				447	457	P5E7	M5E7	M3E7	P3E7	G

(Shown pin assignment is a view from an insertion face of robot side connector.)

■ Details of connector for DeviceNet (Standard) [MC500P-01]

CN71A

1	2	3	4
24V+	24V-	24V+	24V-

CN71C

1	2	3	4
24V+	24V-	24V+	24V-

CN81A



CN81C



Connector
in wiring box BJ1

Connector
in wiring box BJ3

		CN71A	CN71C
Connector	Housing	VLR-04V	VLP-04V
User-side connector	Housing	VLP-04V	VLR-04V
	Contact	SVF-61T-P2.0 (0.5~2.0 mm ²) SVF-42T-P2.0 (0.3~1.25 mm ²)	SVM-61T-P2.0 (0.5~2.0 mm ²) SVM-42T-P2.0 (0.3~1.25 mm ²)
	Retainer	VLS-02V	
	Crimp tool	YC-590(SV*-61T-P2.0) YC-592(SV*-42T-P2.0)	

		CN81A	CN81C
Connector		231-635/010-DM	231-305/037/010-DM
User-side connector	Connector	231-305/037/010-DM	231-635/010-DM
	Crimp tool	231-131	
	Contact	CAN_L, CAN_H :216-301 V-, V+ :216-201 Drain :216-201	
	Crimp tool	:206-204	

(Shown pin assignment is a view from an insertion face of robot side connector.)

(NOTE) Adequate contact and manual crimp tool should be used for each cable.
(Preparation of the user-side connectors are required by customer.)

■ Details of Ethernet connectors (standard [MC500P-01])


CN71A

1	2	3	4
24V+	24V-	24V+	24V-

CN71C


1	2	3	4
24V+	24V-	24V+	24V-

CNLANA



Connector
in wiring box BJ1

CNLANC



Connector
in wiring box BJ3

		CN71A	CN71C
Connector	Housing	VLR-04V	VLP-04V
User-side connector	Housing	VLP-04V	VLR-04V
	Contact	SVF-61T-P2.0 (0.5~2.0 mm ²) SVF-42T-P2.0 (0.3~1.25 mm ²)	SVM-61T-P2.0 (0.5~2.0 mm ²) SVM-42T-P2.0 (0.3~1.25 mm ²)
	Retainer	VLS-02V	
	Crimp tool	YC-590 (SV*-61T-P2.0) YC-592 (SV*-42T-P2.0)	

		CNLANA	CNLANC
Connector	RJ45 plug connector	5-569552-3	5-569552-3
User-side connector	Hood	RJ45 type connector	RJ45 type connector

(Shown pin assignment is a view from an insertion face of robot side connector.)


(NOTE) Adequate contact and manual crimp tool should be used for each cable.
(Preparation of the user-side connectors are required by customer.)

9. Transport procedure


 WARNING	The robot must be transported by personnel who have licenses required for slinging work, crane operation, forklift truck operation, and others. The weight of the robot and controller is listed in the Operating Manual and the Maintenance Manual. Check for the weight, and then handle them according to procedures suitable for the weight.
 WARNING	To lift the robot or the controller, follow the procedures specified in the Maintenance Manual. Following any procedures other than those specified will cause the robot to topple over or drop during transport, thus resulting in accidents.
 CAUTION	During transport or installation work of the robot, pay utmost care not to cause damage to wirings. Furthermore, after installing the robot, take protective measures such as using protective guards so that the wirings will not be damaged by workers or other persons, or forklift trucks or else.
 CAUTION	If hanging wires push the encoder connectors or wiring/piping, they may be broken when hanging the robot. When hanging the robot, please pay attention not to make the wires touch the encoder connectors and wiring/piping.

To transport the robot, make it a rule to use a crane.

At first, put the robot into the configuration shown in figure below and install the four M24 hanger bolts to the swivel base. Then, be sure to lift the robot using 4 hanging wires. It is recommended to use hanging wires of 3.5 m in length and protect areas that contact the robot, using rubber hoses to cover the wire ropes. For the areas to be covered with the rubber hoses refer to figure below.



[MC500P-01]



10. Terms of Delivery and Installation (Specification that contains robot)

1. There are three terms as shown below.

	Terms	Details
1	Delivery on the truck	Robot is delivered on the truck near the entrance of customer's plant. (Installation and test-run is not included)
2	Delivery after installation and test-run	Robot is installed and test-run is performed. (*Teaching with work piece is not included.)
3	Delivery after installation and teaching with work piece	Other than Term2, perform teaching with actual work piece.

Costs differ significantly according to which term you select, so please discuss well and make a decision according to your needs.

2. Operation and maintenance education

The special spot operation guide and the preservation guide are the not included. Consult with each NACHI-FUJIKOSHI office for the training and etc.

11. Consuming power (Robot + Controller)

[MC500P-01]

9.7 kVA (Max.), 3.1 kVA(Average)

(may vary according to the application and motion pattern.)

12. Paint color

Standard color	Controller cabinet	Munsell 10GY9/1
	Robot body	Munsell 10GY9/1

13. Warranty

1 year after delivery. (When running 8 hours/day)

The specification and externals described in this specification might change without a previous notice for the improvement.

 NACHI-FUJIKOSHI CORP.	www.nachi-fujikoshi.co.jp	
NACHI-FUJIKOSHI (CHINA) CO., LTD.	www.nachi.com.cn	
NACHI ROBOTIC SYSTEMS, INC. (NRS)	www.nachirobotics.com	
NACHI EUROPE GmbH	www.nachi.de	
• Concerning the Contact list, please refer to “Contact list (TFDJP-254)”. • NACHI-FUJIKOSHI CORP. holds all rights of this document. No part of this manual may be photocopied or reproduced in any form without prior written consent from NACHI-FUJIKOSHI CORP. Contents of this document may be modified without notice. Any missing page or erratic pagination in this document will be replaced. • In case that an end user uses this product for military purpose or production of weapon, this product may be liable for the subject of export restriction stipulated in the Foreign Exchange and Foreign Trade Control Law. Please go through careful investigation and necessary formalities for export. • This is an original instruction.		